




INSTALLATION MANUAL

1 Charging

Connect the small end of the charger cable to the slot, located on the side of the device. Plug the adapter into the wall socket.



2 Device reboot

If you run into an issue with the application, you can restart the device.

Press and hold the small button on the side of the device for 15 seconds.

The device will turn off and on again. The application will automatically reopen.




3 Sound volume

You can adjust the volume with the large button which is placed on the side of the device.







4 Homescreen




5 Connecting device to internet

Select "Settings" and then WLAN.



From the network list, select the name of your home WiFi.



Enter your password and click 'Login'.